


CLEANING INSTRUCTIONS - METAL CABINETS

- Our cabinets by are designed to be maintenance free. However, it is recommended that the outer surface of the cabinet, and the hinge area, be kept clear from debris and dirt, to ensure correct operation of the hinged door.
- If latches, locks or hinges need to be lubricated, use a “3 in 1” type light oil, removing excess with a cloth.

Finish	Description	Cleaning & Maintenance
Painted Steel	Baked-on Powder Coat Paint	Use a soft cloth and mild soap and water.
Aluminum	Aluminum Without Clear Coat	
313/315/Clear	Anodized Aluminum - Dark Bronze, Black , Clear	
US3	Polished Clear Coated Brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US4	Satin Clear Coated Brass	
US9	Polished Clear Coated Bronze	
US10	Satin Clear Coated Bronze	
US10B	Oxidized & Oiled Bronze	Use a soft cloth and a paste furniture wax. Buff lightly so as not to remove the dark oxide coating where it remains.
US32	Polished Stainless Steel	Use a soft cloth and mild soap and water solution. After cleaning, thoroughly rinse with clear water to remove all traces of the solution and wipe dry to prevent water marks from forming. Stains which resist that treatment can usually be removed by polishing in the direction of the grain with a soft cloth and a non-abrasive stainless steel polish. Test in an unobtrusive area.
US32D	Satin Stainless Steel	

 <p>ACTIVAR INC. Construction Products Group</p> <p><small>www.activarcp.com</small></p> <p><small>JL INDUSTRIES</small></p>	<h3>CLEANING INSTRUCTIONS - METAL CABINETS</h3>
<p style="text-align: center;">HEADQUARTERS & CUSTOMER SERVICE: 4450 WEST 78TH ST CIRCLE, BLOOMINGTON, MN 55435-5416 PH: 800-554-6077 FAX: 952-835-2218 EMAIL: SALES@JLINDUSTRIES.COM WWW.ACTIVARCPG.COM ACPG SOUTHEAST (THOMAS ENTERPRISES): FT MEYERS, FL * ACPG WEST COAST (SAMSON MFG): COMMERCE, CA ACPG WAREHOUSES: DALLAS TX, LANCASTER PA, ATLANTA GA, CHICAGO, IL, SEATTLE WA 1-5-2011</p>	